

# RECRETE

## *Quick Masonry Repair Formulation*

- Quick Set Concrete, Brick and Masonry Repair
  - Apply 1/8" or over 2" Thick in One Coat
  - Sets in 10 to 25 Minutes
  - Use on Horizontal and vertical Surfaces
  - More Than 3 Times Stronger Than Concrete
- 5 Gallons Covers Approximately 24 Square Feet at 1/4" Thickness.

**RECRETE** Quick repair may be used to patch concrete, masonry and brick. Also may be used to repair side walks, driveways, swimming pools, foundation walls and other similar masonry structures.

As simple as 1-2-3 **RECRETE** can be in place. Mix with water and work the material into the surface. In 10-25 minutes at temperatures between 60-75 degrees Fahrenheit, Recrete will be setup and ready for light traffic in 2 hours.

### **PREPARATION**

The surface to be repaired must be clean, stable, dry and free of sealers and paints. Any loose or unstable material not removed will cause separation. Surface temperature must be above 45 degrees Fahrenheit.

### **DIRECTIONS**

Approximately 5 quarts of water are required to mix a 5 gallon container. Always add and mix the RECRETE into the water. When you arrive at the proper consistency, rub or scratch the mixed material with a trowel on to the surface to be repaired. Smooth trowel to the desired finish. Mixed material must be used in 10 to 20 minutes, depending on drying conditions and temperatures. As long as the mixed material is workable, it is usable. DO NOT add water to material once it has started to cure to prolong pot life, this will cause cracking of the finished patch.

### **CAUTION**

This product contains Portland Cement. Prevent contact with eyes or prolonged contact with skin. Skin areas that have been in contact with wet or moist Portland cement should be washed promptly and thoroughly with fresh, clean water. Consult MSDS sheets for additional information.

**C-265**